

PREPARATION

Using a broom or leaf blower, blow or sweep out debris from cracks. Cracks must be free of debris prior to application.

Some separation/settling may occur over time. Stir/mix KOLD-FLO® pourable crack filler to achieve a consistent mixture.

Sub-Surface Preparation

- Be sure no undermining of the pavement base has occurred. Undermining can be severe and require backfilling before any application of KOLD-FLO® crack filler.
- If there is presence of undermining, fill the crack partly with clean sand or backer rod. KOLD-FLO® crack filler fills from bottom to top.
- If undermining has occurred and is not filled or isolated with backer rod, additional KOLD-FLO® crack filler may be required to fill the undermining and the crack.
- KOLD-FLO® crack filler will continue to flow into undermine until filled.
- Continue to apply KOLD-FLO® crack filler until crack is level full.

PLACEMENT

1. Product can be applied directly from the bottle or pail, using a pour pot or UNIQUE's CRACK-N-TACK® portable pump.

2. Pour or pump KOLD-FLO® crack filler into $\frac{3}{4}$ of the length of the crack. Allow a few minutes for KOLD-FLO® crack filler to seep completely down into the crack.

3. Squeegee KOLD-FLO® crack filler into the crack using a "U" or "V" shaped squeegee. Proper squeegeeing will decrease surface cure time and avoid tracking of KOLD-FLO® crack filler.

A second application may be necessary for cracks deeper than two inches. Multiple coats may be applied for deeper and undermined areas.

If KOLD-FLO® crack filler continues to sink in undermined areas of the crack, add additional clean sand and KOLD-FLO® crack filler (Allow 1-2 hours curing time between coats).

CURING

When properly applied, KOLD-FLO® crack filler can be driven over within 30 minutes without tracking.